

- 1) collegare il cavo USB al PC/MAC
- 2) mettere l'Action/Screen/Apnea in modalità PC, come spiegato sul libretto di istruzioni
- 3) collegare il computer all'interfaccia USB
- 4) far partire SeacSync
- 5) cliccare su Sync Watch

Se ci sono problemi nello scarico dei dati, o se il PC non rileva il computer, l'utente può scaricare i driver da installare sul PC/MAC.

I driver possono essere scaricati partendo da questo link:

<https://www.silabs.com/developers/usb-to-uart-bridge-vcp-drivers?tab=downloads>

Normalmente i problemi non dipendono dal computer subacqueo o da SeacSync, ma sono causati dal PC/MAC. Infatti possono essere causati dall'antivirus, dalle impostazioni utente, o dal software già installato che va in conflitto con SeacSync.

- 
- 1) connect the USB cable to the PC/MAC.
  - 2) put the Action/Screen/Apnea in PC mode, as explained in the user manual
  - 3) connect the computer to the USB interface
  - 4) start SeacSync
  - 5) click on Sync Watch

If there are problems downloading data, or if the PC doesn't detect the computer, the user can download drivers to install on the PC/MAC.

Drivers can be downloaded starting from this link:

<https://www.silabs.com/developers/usb-to-uart-bridge-vcp-drivers?tab=downloads>

Antivirus, user settings, or software already installed software may create conflicts with SeacSync.